



## Maxisafe Suspension Trauma Straps

ZSTS01N

The Maxisafe Suspension Intolerance Straps can help avoid the effects of suspension trauma in the event of a fall or during prolonged hanging. The suspension intolerance strap can be attached to any full body harness. They are positioned so that the worker can step into the straps and reduce the pressure of the harness on the body and promote blood circulation.



### Steps to Use

1.



Un-zip the pouches fitted on both sides of Harness

2.



Hold the 2 straps together

3.



Connect the straps with each other making a loop with the help of easy-to-use buckle

4.



Put you feet into the loop

5.



Stand onto the loop, so that the thigh strap are free to move

6.



Adjust the sit strap towards the front to release pressure and give a seat-posture

### Product Specifications

Product Code	Description	Pack Qty	Carton Qty	Barcode
ZSTS01N	Maxisafe Suspension Trauma Straps	1	1	XXXXXXXXXXXX

[CLICK HERE FOR PRODUCT SPEC](#)

there's safe and there's Maxisafe.

Your Maxisafe Dealer:

[www.maxisafe.com.au](http://www.maxisafe.com.au)  
1300 062 947 | [sales@techware.net.au](mailto:sales@techware.net.au)

© Maxisafe is a registered trademark of Techware Pty Ltd